



Focusing the Camera

How to use the shutter button on your PowerShot A4000 camera to insure your shots are in focus.

Written By: Ansley Gardner



Step 1 — How to Focus the Camera



- The shutter button is highlighted in red. To focus your camera, press this button down halfway.
- Your camera will beep twice and a frame will appear around the object on your display screen that is being brought into focus.
- Once this frame appears on the display screen, press the shutter button all the way down, taking the picture.

⚠ The camera will make a shutter sound. Make sure to hold the camera very still until this sound ends.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-09 04:59:26 PM.